

DrizAir 1200 & EV1800 Touchpad Change Guide

Unplug machine from mains

Check switch on touchpad is set to correct position for machine – 110volt or 230volts

Please Note – The Dri-Eaz 1200 is sold in a 110volt version or 230volt version, but the touchpad will fit on both – just set the slide switch on the back of the touchpad to the correct setting.

This switch will **NOT** allow the machine to run on the other voltage otherwise damage will occur – see serial number plate for correct voltage for your machine

Remove 4 screws holding touchpad down

Remove sensor plug (2 thin blue wires)by squeezing and pulling out – this will give you more room to transfer over the other wires

Carefully remove each wire from the old touchpad and insert in same place on new one (one at a time)

Reconnect sensor wire

Re mount touchpad with 4 screws

Check touchpad works on machine

If you need any help contact Dri Eaz on 01908 611211